



UrbanMax™ Portable Blender

The UrbanMax™ Portable Blender is the ideal solution for prepping drinks on the go!

Features and Benefits

- **Off Centered Blades** - are designed to create a vortex that makes the food hit the blades more times resulting in a smooth outcome.
- **Superior Battery Performance, 10 Drinks with one Charge** - Two High Capacity 1200mAh rechargeable lithium batteries for a total of 2400mAh, provide 10 drinks with one single charge.
- **Enhanced Blending Performance** - Ribs are added on the inside of the tumbler to optimize the blending performance.
- **Cordless Freedom** - Powered by a lithium ion battery, this compact blender is ideal to mix your favorite drink anytime, anywhere.
- **Easy and safe to use.** The **Smart Engine Lid** activates only when the cover is in the closed position.
 - o Automatic power off when you remove the cover.
 - o The embedded magnets notches in the Tumbler and Motor Cover so that the motor will operate only if the connection is properly made and the blades are not exposed.
- Once your drink is made, replace the cover to take it on the go with the additional **On the Go Cover**.
 - o Ribbed walls along the length of the tumbler is key for blending performance.
 - o Graduate measuring markings makes easy to follow smoothie recipes. Also includes a max filling line.
 - o Total capacity of 18 oz./ 530mL and usable capacity of 11.8 oz./350mL
- Polished line marking beside the charging dock helps to indicate the **correct charger alignment**.

Use & Care

Before Blending:

- Please use fruits, vegetables or other food in pieces no bigger than $\frac{3}{4}$ inch/ 2 cm.
- If using frozen fruits or vegetables, thaw for at least 10 minutes in the liquid that you will use for your preparation, before blending. This will keep the engine from getting stuck.
- Avoid using ice cubes, as they will dull the blades over time. When desired, use crushed ice or add ice cubes after blending.

Ready to Blend!

- When mixing ingredients, always put solid ingredients in the Blender first, followed by liquids.
- To avoid overflow, do not exceed the maximum fill line.
- This product has different safety measures. If the Smart Engine Lid is not placed on the Tumbler and fully closed, the engine will not start and the light will blink red; this keeps blades from running while exposed.
- In order to activate Blender, align notches on base and cover. When the Smart Engine Lid is in correct position, light will blink green, indicating it is ready for use.
- Double-click Start/Stop button to start engine and blades will start to rotate.
- Turn Blender upside down so cover is fully in contact with a flat surface for proper blending.
- Pre-set cycle lasts 40 seconds; after that, engine will automatically stop.
- If desired, stop the cycle by clicking Start/Stop button once at any time during a cycle. Otherwise, it is recommended to let engine run a full 40-second cycle.
- Run cycle twice for smoother results.

How to Clean:

- Before first use, hand wash and dry the product.
- Tumbler and on the go cover are dishwasher safe, using a 149 F/ 65 C temperature.
- Smart Engine Lid should be hand washed to protect engine, please rinse carefully. Do not put the engine in the dishwasher or submerge in water.
- Wash or rinse immediately after each use.
- The spout comes with a removable silicone cap. Make sure to clean to silicone piece, by carefully removing it by gently pulling outwards from the inside and washing it by hand.
- **Cleaning Tip:** after use, fill Tumbler with warm water (not hot) and a few drops of dish soap, place the Smart Engine lid on and run a cycle. This is a great way to clean the tumbler and blades at once

Tupperware®



UrbanMax™ Portable Blender

Demonstration Ideas & Tips:

- Share visual and relatable phrases in your product demonstration:
 - o Provides the possibility to prepare and enjoy fresh, healthy, customized drinks anytime, anywhere. Smoothies, shakes, juices and other liquid beverages are all possible.
 - o With the UrbanMax™ Portable Blender you can conveniently prepare other foods like sauces, dressings or milkshakes when you only need a small quantity and don't want the hassle of cleaning your whole blender.
 - o The Smart Engine Lid and On the go Cover have a drinking spout to drink directly from the tumbler but also wide enough to fit your favorite straw and use it to enjoy your drink. The Tupperware Eco Straw is made to be used with the UrbanMax™ Portable Blender. Use it over and over again and keep it hygienic thanks to its matching straw brush.
 - o In case you have a small portion or for any other reason, you can stop the 40 second pre-set cycle at anytime by pressing the Start/Stop button once.

Recipe:

ORANGE SUNSHINE SMOOTHIE

Serves: 1
Serving size: 1½ cup
Total time: 5 mins.

¾ cup frozen mango chunks
½ cup frozen banana slices
1 cup orange juice

1. Allow frozen fruit to slightly thaw for 10 min., then add to UrbanMax tumbler along with orange juice.
2. Place cover on and press start button twice then turn blender upside down. Blend for 1 cycle while gently shaking/rotating to optimize blending performance. Serve immediately.

Recipe:

SALTED CARAMEL PRETZEL MILKSHAKE

Serves: 1
Serving size: 1 ½ cups

1/3 cup milk of choice
10 small, crunchy pretzels, broken into pieces
1 pinch of salt
¾ cup soft vanilla ice cream, divided
3 tbsp. caramel syrup (±3 tbsp)

1. Add milk, pretzels, salt, half of vanilla ice cream and caramel syrup to UrbanMax tumbler. Place cover on and press start button twice then turn blender upside down. Blend for 1 cycle.
2. If necessary, gently shake/rotate tumbler to optimize blending performance. Add remaining ice cream, cover and blend for one additional cycle. Garnish as desired and serve immediately.

Tupperware® UrbanMax™ Portable Blender

Two Powerful
1200mAh batteries.

White light blinking
indicating it's charging.

USE IT ANYWHERE.

Tupperware®



URBANMAX™

Portable Blender



USE IT ANYWHERE.

Tupperware®

Two color choices!

Tupperware® UrbanMax™ Portable Blender

You'll want to share.
Wide opening.



USE IT ANYWHERE.

Tupperware®

- Includes on the go cover
- 2x press to start
- Ergonomic no spill spout
- Wireless, rechargeable blender
- Easy carry strap
- 350ml capacity
- USB charging cable
- Ribbed walls for optimal blending

URBANMAX™
Tupperware®

