

Tupperware®

Endless popping, endless flavor, endless fun!

While Supplies Last!

January 18 at 12 P.M. ET through January 24 at 11:59 P.M. ET.

Tupperware®
WOW Pop
Microwave Popcorn Maker



A. NEW! Tupperware® WOW Pop Microwave Popcorn Maker

Ingenious design and simple functionality makes it easy to make anything from healthy popcorn popped without butter or oil to endless sweet and savory creations. Dishwasher safe. ©

9110 ~~\$29~~



B. 1³/₄-cup/4.1 L Servalier® Bowl

All-in solution for food storage as well as food serving, featuring a tight seal that easily closes when pressed in the center.

89111 ~~\$27~~ **\$20**



C. 1¹/₂-cup/400 mL Servalier® Bowl

Set of four bowls with tight seals that easily close when pressed in the center.

89112 ~~\$32~~ **\$25**

**SAVE OVER 30%
Endless Flavor Get It All Set**

From healthy to sweet, you can create endless recipes, store them and have them ready to share with this set. Includes A-C.

89113 ~~\$88~~ **\$59**

JOIN. HOST. SHOP.

See next page for more product details and recipes!



Tupperware®

Create endless recipes with the Tupperware® WOW Pop Microwave Popcorn Maker, from healthy to sweet and savory.

A POP of design

Glass insert tray

The combination of the glass and silicone unlock popping efficiency promoting optimal kernel heating and popping.



A POP of innovation

Vent & Shake lid

Vents while popping, shakes out unpopped kernels and keeps seasonings from falling out.



A POP of convenience

Easy to use, Easy to clean

- Stands up for easy popping and serving, base nests for compact storage.
- Wide opening for easy snacking.
- Dishwasher safe.



Movie Popcorn

A POP of joy

Ingredients

- 2 tbsp. unsalted butter, softened
- ¼ tsp. salt
- Black pepper to taste
- ¼ cup popcorn kernels

Preparation

1. Combine the butter with salt and pepper. Set aside.
2. Place kernels inside popcorn maker, cover in open position and microwave at the recommended time. (If using for the first time, start with 3 minutes, then listen carefully to the popping until it slows down to about 2 seconds between pops and stop the microwave).
3. Keep cover in open position and immediately shake out the unpopped kernels.
4. Add butter to hot popcorn, place cover in closed position and shake gently for about 30 seconds until butter is fully incorporated. Serve immediately.

Sweet Crunchy Peanut Popcorn

A POP of taste

Ingredients

- 2 tbsp. unsalted butter, softened
- 2 tbsp. granulated sugar
- 4 ½ tbsp. lightly salted peanuts, chopped
- ¼ cup popcorn kernels

Preparation

1. Combine butter with sugar and set aside.
2. Place kernels inside popcorn maker, cover in open position and microwave at the recommended time. (If using for the first time, start with 3 minutes, then listen carefully to the popping until it slows down to about 2 seconds between pops and stop the microwave).
3. Keep cover in open position and immediately shake out the unpopped kernels.
4. Add the butter mixture to hot popcorn, place cover in closed position and shake gently for about 20 seconds. Microwave for 15 seconds in closed position, shake and microwave again for 15 seconds.
5. Add chopped peanuts and shake one last time. Serve immediately.

